

Lemke Crest Gate Black Remote User Manual



One Black Remote Key was issued free of charge per unit.
Additional Black Remote Key can be requested, and it will be billed around \$80 in Owner's next levy bill.

Top Left Button – will open the Entry Gate

Top Right Button – will open the Exit Gate

Please **replace the battery when necessary: 12V 27A (or A27)**

Please don't remove the serial number sticker of internal back cover, it is for office tracing purpose in case of lost or stolen.



IF you still don't have one or would like to request additional Black Remote, please fill below form:

<https://lemkecrest.com.au/appl/main-gate-remote/>



SCAN to Gate Remote